



User Manual

Mounting bracket RL

4x

- PL** Instrukcja montażu – mocowanie RL
- CS** Pokyny k instalaci – konzole zmien na montážní profily RL
- DE** Montageanleitung – Wandhalterung RL
- ES** Instrucción de montaje – soportes RL
- FR** Instruction du montage – Support de montage RL
- IT** Manuale d'uso – staffa di fissaggio RL
- NL** Gebruiksaanwijzin – muur bevestiging RL
- RU** Инструкция монтажа – креплений RL
- SK** Pokyny k inštalácii – montážne profily RL

